DOORS AND WINDOWS

Artisan Slider (OS-20) Specification File



Contents

Specification Overview	04
Security	07
Optional Extras	08
Inline Slider Make-Up	09
Performance and Limitations	10
Master Configurations	11
Technical Drawings	16
Gaskets	40
Installation Guide	41

Specification Overview



Internal view of the Origin Inline Slider



Profile specification

Frame Depth	2 options: 116mm (double track) and 182mm (triple track)
Sightline	20mm interlockers, 159mm central locking stiles (if used) 44mm and 77mm sightlines also available on the Patio Slider.
Track Height	44mm (double and triple track)
Maximum Individual Panel Size	2200mm wide x 3000mm tall* *individual panels cannot exceed 6sqm *the height of an individual panel cannot exceed 3 times its width
Minimum Individual Panel Size	550mm wide x 1600mm tall

Features

- Up to a 20-year guarantee including gaskets and seals*
- Up to a 10-year guarantee on glass*
- Ultra-slim 20mm sightlines
- Available in any RAL finish
- Concealed running gear and track
- Minimum of 6 points of locking (internal lever and cylinder only)
- Weather testing BS6375 part 1 certified
- Can accommodate large panel sizes

Glazing options

- Structurally bonded system (Fixed panels will require bonding on site by the installer)
- The premium low-e toughened glass used is a dependable double glazed unit. Constructed of two toughened sheets a minimum of 6mm on both the inward and outward facing panes, making it highly durable as well as thermally efficient.

Options and extras

- Up to 6 panelled configurations
 these can be all sliding or a combination of fixed and sliding
- All RAL colours available
- Lever options: 7015M, 7016M, 9005M, 9910G
- Drip bar available
- 180mm and 225mm cill options available

*Guarantee based on location of where the doors will be installed.

Full terms and conditions can be found on the Origin website - origin-global.com/terms-and-conditions.

The Origin Inline Slider is available in over 150 colours...



Anthracite Grey (7016M)	Jet Black (9005M)	Black Grey (7021M)
RAL 4010	RAL 6019	RAL 2004
RAL 5013	RAL 7001	RAL 1003
RAL 6027	RAL 6021	RAL 5023

Covering everything from the favourite metallic shades through to the more extensive palettes, we've got a colour available that's guaranteed to suit any home or building style.

For the full range, visit origin-global.com

Dual colour and woodgrain options are not available.

Security

Origin's Multi-Point Lock

Each door is equipped with an ultra-secure multi-point locking system, which features a minimum of six points of locking. Depending on the size of the door, this may increase.



Cylinder

TS007 1 star cylinder Internal cylinder only



Optional Extras

Handles

Every Inline Slider is fitted with a flush-faced lever handle, which offers a look as sleek as the doors themselves.

It's available in four attractive colours: 9910G, 7015M, 7016M, 9005M



Cills

Choose from our 2 cill options. These can also be powder-coated to match the doors.




180mm cill



Drip Bar

A drip bar option is available. It is situated towards the bottom of the door to deflect rainwater and prevent large pools of water from gathering.

Inline Slider Make-Up



Make-up is dependent on the configuration chosen.

Performance and Limitations

Origin Thermal Ratings

u-Value

1.4W/m²K

Weather Rating

Air Permeability	Class 4
Water Tightness	Class 7A
Resistance to Wind Load	Class A3
Exposure Category	1200

Performance Testing

BS6375 Parts 1, 2 and 3 Certified

Accreditation

ISO 9001

Size Limitations

Maximum individual panel size:

2200mm wide x 3000mm tall*

*individual panels cannot exceed 6sqm. The height of an individual panel cannot exceed 3 times its width

Minimum individual panel size:

550mm wide x 1600mm tall

Building Regulation Requirements

New Build and Extensions 2.0 W/ (m2K) Replacements 1.8 W/ (m2K) Energy Rating E or better All doors must conform to


All doors must conform these requirements


Glazing Specifications

Standard Glass	6 or 8mm Toughened / Warm edge / Low E Toughened
Laminate 6.8 and 8.8 Glass	6.8 or 8.8mm Laminated / Warm edge / Low E Toughened
Solar Reflective	Sunguard SN 70/37


Master Configurations


2 panel





3 panel







6 panel

+	•	•	•	+
---	---	---	---	---

	•	•	4	•	•	
--	---	---	---	---	---	--


4 panel







Inline Slider

Master Configuration: 2 panel (2+0)




Configuration Key






14 - Sliding panel to double frame (bottom track) detail

See page 29



Master Configuration: 3 panel (shown is 2 sliding and 1 fixed - 2+1)




Fixed pane can be specified
on the left or right

All panels can slide or flexible opening

211


See page 11 for configurations


Configuration Key




Technical Drawings

1 Fixed interlocker to sliding interlocker detail







2 Flush fixed interlocker to sliding shallow interlocker


















6 Sliding interlocker to sliding interlocker detail







Inline Slider


origin

21

7 Fixed panel to double frame (bottom track) detail









Inline Slider


9 Fixed panel to double frame (jamb) detail






10 Fixed panel to double frame (top track) detail































15 Sliding panel to double frame (jamb) detail





16 Sliding panel to double frame (top track) detail







origin

3












19 Sliding panel to triple frame (top track) detail









21 Drainage details double frame


Frame Drainage with Fixed Panel




Frame Drainage









Frame Drainage









Gaskets

Fixed Panel Wedge Gasket -	Sash Wedge Gasket	Sash Wedge Gasket
G00069	W401-3 - G00125	W401-4 - G00126
Sash Wedge Gasket	Sash Wedge Gasket	Woolpile_7x7mm
W401-5 - G00127	W401-6 - G00121	G00096
W401-5 - G00127	W401-6 - G00121	G00096








Installation Guide

1. Prepare the opening










FIG 2

Measure aperture width.

Measure aperture height.




Level the threshold in both directions, packing every 500mm apart for the length of the opening.




Lay frame profiles in front of aperture, being careful not to scratch the powder coat.

2. If applicable, join the top/ bottom frame profiles together






Apply suitable sealant on ends of profile and around the pre-inserted frame connectors.



Connect the frame profiles together.





Fix the frame profiles together and repeat for remaining frame pieces.

3. Connect the jambs and bottom track





FIG 8

Apply suitable sealant to profile ends.



Insert alignment cleats to the frame. If set includes a fixed panel, one alignment cleat is required per corner and should be fitted in 25mm rebate.






FIG 10

Join jamb to bottom track.



Tighten the cleat join with a 4mm Allen Key and screws provided.






FIG 12


Check join, remove excess sealant and repeat process for second jamb.




4. If applicable, connect the fixed interlocker (only applicable for sets with fixed panels)



Note: Flush fixed interlockers do not require end plates.




Align fixed interlocker to notch on bottom track. Ensure profile position is as per sections above.




Seal holes with a suitable sealant.





Fix interlocker end plate with 3.9 x 16mm screws. Repeat process at both ends of profile.



Align flush fixed interlocker to notch on bottom track. Ensure profile position is as per sections above.

FIG 16






FIG 17

Seal holes with a suitable sealant.



Fix interlocker in place with 3.9 x 16mm screws. Repeat process at both ends of profile.





5. Lift the frame into the aperture




FIG 20

Lift frame into the aperture, ensuring drainage caps are situated externally.





FIG 21


Insert packers above both jambs.

6. Fix the bottom track



Where possible, fixing points should be on both sides of the frame, in a zig-zag pattern.









FIG 23

Use an HSS bit to drill and countersink an appropriate sized fixing hole through the frame. This should be no more than 150mm from the external corner of the frame.


FIG 24

Insert suitable sealant to fixing hole, then screw preferred fixing in place. Repeat process along the bottom track, ensuring fixings are within 900mm intervals.

7. Level and fix both jambs



56



Use an HSS bit to drill and countersink an appropriate sized fixing hole through the frame. This should be no more than 150mm from the external corner of the frame.

FIG 27





FIG 28

Screw preferred fixing in place. Repeat process along the jambs, ensuring fixings are within 600mm intervals.

8. Fix the top track




Use an HSS bit to drill and countersink an appropriate sized fixing hole through the frame. This should be no more than 150mm from the external corner of the frame.




Insert suitable sealant to fixing hole, then screw preferred fixing in place. This must be done at both ends of the top track.

FIG 30




Accurately measure the internal frame dimensions.




Pack out across the top track for consistent internal frame sizes. Ensure the track doesn't bow in any direction.





Use an HSS bit to drill and countersink an appropriate sized fixing hole through the frame. Insert sealant to fixing hole, then screw preferred fixing in place. Repeat process along the top track, ensuring fixings are within 900mm intervals.



Measure diagonally from corner to corner to check the frame is square.







FIG 35

Seal the drainage isolator in place, ensuring ends of profile are sealed with edge of frame.

9. Install the sash

Install sashes, working from inside to outside.



Insert all running gear profiles into necessary track channels.






FIG 37

Level the running gear profiles by adjusting the roller height with a 3mm Allen Key.






FIG 38





FIG 39

Swing bottom of sash above running gear.



Drop sash on to running gear, ensuring the running gear sits within the bottom of the sash.








FIG 41

Check to ensure bottom of sash and running gear components are flush at both ends.



If applicable, repeat process for remaining sashes.



Fix anti-lift blocks above each sash corner when the sash is in the closed position. Fix using 3.9 x 25mm screws and position no more than 60mm from the external corner of the sash.







FIG 44

Level the lockstile to ensure the sash is parallel to the frame. Repeat for all opening sashes to ensure the interlockers line up correctly.



Align centre keeps with corresponding locking points (situated directly above and below handle).







FIG 46


Working from bottom to top, adjust keep positions if necessary. Keeps can be packed out using the 0.5mm and 2mm packers supplied. Adjust keeps until the handle engages correctly, and the key in the lock cylinder turns smoothly.




If more adjustment is required, use a 3mm Allen Key to adjust the locking point.

FIG 47


10. If applicable, install the fixed panel



Inline Slider



Place 10mm anti-lift packers into track channel.



Insert glass into frame and slide over on to pre-applied structural sealant in interlocker. Pack out below glass, so it is central in the frame.

Use a straight edge or long level along the fixed interlocker to ensure straightness. Pack out accordingly between edge of glass and jamb.

FIG 52



FIG 53

Secure frame bead in place. First clip top and bottom of bead, then proceed to clip in the centre.

Inline Slider







FIG 54

Fit wedge gasket between glass and outer frame, on both inside and outside glass faces.



Apply bead of structural sealant along the length of interlocker (both inside and outside faces). Leave to fully cure before operating the set.

11. Install frame covers



Clip in the vertical frame cover pieces.






FIG 57

Clip in the horizontal frame cover pieces.



Contact

Accounts	
t 08448 802 371 or 01494 416 895	e Finance@origin-global.com
Marketing	
t 08448 802 374 or 01494 416 897	e Marketing@origin-global.com
Sales Operations	
t 0808 168 5816 or 01494 686 868	e OrdersNorth@origin-global.com
	e OrdersSouth@origin-global.com
Solutions	
t 08448 802 373 or 01494 416 896	e Solutions@origin-global.com
Fleet and Logistics	
t 08448 802 378 or 01494 416 898	e Logistics@origin-global.com





origin doors and windows Origin Global HQ, Stuart House, Castle Estate, Coronation Road, High Wycombe Buckinghamshire, HP12 3TA

- t 0808 168 5816
- e enquiry@origin-global.com
- $\textbf{w} \ \text{www.origin-global.com}$

Origin Northern Centre of Excellence, Taurus Park, Europa Boulevard, Westbrook, Warrington, Cheshire, WA5 7ZT

- t 01925 907 907
- e enquiry@origin-global.com
- w www.origin-global.com